



TABLE BASE ASSEMBLY

Stainless Steel - Bolt Down Bases



Part List:

- A- Base Plate
- B- Connecting Rod
- B-1 - M12 Hex Nut
- B-2 - Flat Washer
- B-3 - Lock Washer
- B-4 - M12 Self-Locking Hex Nut
- C- Column
- D- Top Plate
- E- Base Plate Cover
- F- (x4) Locating Pins
- G- (x4) Anchor Bolts

Instructions:

- Step 1** - Thread the connecting rod (B) into the base plate (A) until it is flush with the bottom of the plate and tighten down the hex nut (B-1) with a wrench. Once the nut is tight insert two column locating pins (F) into the base plate.
- Step 2** - Slide the column (C) over the rod (B) making sure the column bracket fits on the rod and locating pins as shown in step 2 & 5.
- Step 3** - Slide the stainless-steel cover (E) over the column (C) to cover the base plate (A).
- Step 4** - Insert the last two locating pins into the top plate (D).
- Step 5** - Slide the top plate over the rod assembly and make sure the top alignment pins fit into the column bracket.
- Step 6** - Slide the flat washer (B-2) and lock washer (B-3) over the connecting rod (B) and tighten with the self-locking nut (B-4). You are now ready to bolt the unit to the floor. Anchor bolts (G) are included for a concrete floor.

